

HOLLOW METAL FRAME INSTALLATION INSTRUCTIONS

STEP 1

Construct wall w/ rough opening height to finished opening height plus 1". Rough opening width: for 2" inch reveal - opening width plus 2-3/4". Inside finished opening: subtract 2.75" from width & 1" from height of rough opening.

STEP 2

If optional base anchor is used, notch drywall in that area.

STEP 3

Install one jamb in position on wall.



STEP 4

Make sure jamb is square and plumb.



STEP 5

Insert frame header under the corner clips of the jamb and raise the header into position.



STEP 6

Insert the corner clips of the remaining jamb into the opposite end of the header and position jamb on wall.



STEP 7

Square and plumb frame in opening. Install fasteners in face of frame or on returns, making sure that no fasteners are installed where door hardware will mount. (12" up and down on hinge side).

STEP 8

Install (4) No. 8 x 1/2 sheet metal screws at the corners of the header to attach header to jambs. (Mandatory for fire rated frames).